

**TABLE 2 - SCULPTMETAL™ INSTALLATION PROCEDURES**

SUBSTRATE	PROCEDURE
Exterior Concrete, Masonry, Stucco on Block, Stucco on Lathe	Prepare surface as indicated in Table 1. Predrilled pieces may be fastened with screws and back plates or toggle bolts to wall.
Polymeric Stucco over Polystyrene Board	Stainless steel pins must penetrate through polystyrene panel to structural base. Use approved waterproof caulk adhesive at point of penetration to prevent water from entering screw hole
Interior Gypsum Board, Two-Coat Plaster	Prepare surface as indicated in Table 1. Apply construction adhesive to piece and press into place as per adhesive manufacturer's instructions. Predrilled pieces may be fastened with screws and anchors or toggle bolts to wall.

**Note:** Tables 1 and 2 assume wall is structurally sound, stable, and weather tight.

**Note:** Ultimate connection design is the responsibility of Building Design Engineer, Architect or otherwise responsible person charged with the connection design.

**Warning!** Failure to follow these instructions or to install product in an insecure or unsafe manner can result in property damage, serious injury or death. Personal safety equipment required for installation. See SculptMetal(tm) Installation Specs 3.2 A